

Priming the Black Berkey Elements

■ You must prime your filters before installing your system. Please read these instructions carefully.

Included in this kit with a Berkey system:

1. Universal Prime rite primer
2. Aeration clip
3. Fluoride element adapter Prime rite (PF-2)
4. Red food coloring vials x2



1

Attach the blue silicone primer to the spigot. Make sure the tip of the primer is raised as close as possible to the end of the spigot.



2

Push the stem of the Black Berkey element into the blue primer.



3

Keep one hand on the filter and slowly open the spigot. Use cold water only and do not let them hang freely.



4

Gradually increase water flow until you reach a moderate flow.



5

If the blue primer swells (like a balloon), decrease water pressure.



6

Run water until it begins to bead across the entire surface. Leave for approximately 1 minute to prime completely.

7. You are now ready to install your Black Berkey elements.

✓ **Your Black Berkey filters are primed and ready to be installed in your Berkey system.**